# Flow limiter SP/SMB3 Flow limiter SP/SMB6

for circulating-oil lubrication systems



### Advantages

- reliable perpetual dispensation of individual volume flows
  - self-adjusting metering, thus identical volume flows despite different back pressures.
  - wide viscosity range, virtually independent of temperature and viscosity, thus the system conditions are stable

### easy system design

The demanded volume flow and flow limiter nozzle respectively, are determined during projection.

- easy startup Pre-adjusted volume flows enabling short start up periods.
- effective monitoring of the volume flow signal transmitter or piston detector react to deviations of the volume flow from approx. 15%.
- wide range of operation, up to 200 bar
- optional ATEX version or integrated gear indicator for volume flow


Flow limiters are used in large circulating-oil lubrication systems. The task of a flow limiter is to divide up the volumetric flow of the main line into parallel individual volumetric flow quantities and to "limit" these according to requirements, or to keep them constant. The volumetric flow generated is independent of the system pressure and virtually independent of viscosity.

When exchangeable plug-in nozzles are used, it is possible to adjust the volumetric flow of the flow limiter as follows:

SP/SMB3 in steps from 6.0 to 38.0 l/min SP/SMB6 in steps from 25.0 to 132 l/min This enables a subsequent adjustment of the volumetric flow.

The volumetric flow can either be monitored by a sensor or a piston detector (also retrofittable). A fault signal is emitted when the volumetric flow drops to approx. 85 % of the rated flow.





The SP /SMB3 and the SP/SMB6 flow limiter comes with two throttles installed in series  $(D_1, D_2)$ . Throttle  $D_1$  is an interchangeable plug-in nozzle which, as a nonadjustable orifice, determines the rated volumetric flow. Nonadjustable orifice  $D_1$  is available with different nozzle cross sections (see tables on pages 8 and 10).

Throttle  $D_2$ , on the other hand, is an adjustable orifice that has a variable nozzle cross section depending on the position of control piston RK. Displacement of the control piston RK against the spring force (F) automatically changes the flow resistance of throttle  $D_2$  in such a way that the differential pressure at nonadjustable orifice  $D_1$  remains constant, and thus the volumetric flow as well.  $p_1 \cdot A = p_2 \cdot A + F$  resp.  $p_{1/2} = p_1 - p_2 =$ 

F/A = constant

The result is:


the difference in pressure upstream and downstream of the variable nozzle is held constant by adjustable orifice  $D_2$  (pressure balance).

The condition for this function is that the system pressure  $p_1$  is always greater than the sum of the pressure drops in and after each flow limiter.


$$p_1 > p_{1/2} + p_3$$
  
For this reason, the pump volume flow should  
exceed all individual flow quantities by  
approx. 15 %, i.e.,

 $Q = 1.15 \bullet (\Sigma Q_i).$ 

Due to the very short throttle length of the plug-in nozzle  $D_1$ , the control characteristic is virtually independent of viscosity and temperature within the specified viscosity range.




### Flow limiter SP/SMB3



### Design Flow limiter SP/SMB3


with signal transmitter version E4



Green and yellow LEDs light when Go signal received, when yellow LED goes out => fault signal.

## Design Flow limiter SP/SMB3


with signal transmitter version E5



## Design Flow limiter SP/SMB3

with proximity switch E6






Normal position / go position

See important product usage information on the back cover.


= pin 2 glosed

### Flow limiter SP/SMB6




## Design Flow limiter SP/SMB6

with signal transmitter version E4



# Design Flow limiter SP/SMB6


with signal transmitter version E5



# Design flow limiter SP/SMB6










SP/SMB6 with proximity switch E6, 24 V





Fault position when nozzle clogged =pin 2 open Normal position / go position =pin 2 glosed

### Technical Data SP/SMB3, SP/SMB6

#### General information

Hydraulics

Nominal volumetric flow (also see related tables on pages 8/10)

SP/SMB 3	 stepwise	from	6.0	to	38 l/min	
SP/SMB 6	 stepwise	from	25 t	0	132 l/mir	۱

Working pressure p<sub>1</sub> without adaptations 5 to 200 bars **E4/E5** with signal transmitter 5 to 85 bars E6 with proximity switch 5 to 200 bars

Required differential pressure between input pressure  $p_1$  and output pressure  $p_3 \ge 5$  bar

Lubricant ..... mineral oils, synthetic oils and ecological oils

Operating viscosity  $\dots 20$  to 600 mm<sup>2</sup>/s

Proximity switch E6

Туре	inductive PNP (normally closed)
Operating voltage	12 to 36 V DC
Current rating	100 mA
Operating temperature	25 °C to +80 °C
Short circuit protection	included
Type of enclosure (DIN	40 050) IP 67 <sup>4</sup> )

 The ATEX signal transmitter is identical to the basic version E5. The electric connection values of the ATEX signal transmitter have to be considered. The signal transmitter must only be used in combination with the disconnector unit.

2) Sufficient spark protection required.

3) Pay attention to maximum switching capacity.

4) Please order coupler socket separately; see accessories

Signal transmitter E4 / E5		
netic switch		
netic/reed contact		
+ 90 °C		
MgPb F38, neutrally anodized, Connector polyamide		
kg		
ATEX Version 1)		
30 V DC		
max. 100 mA		
NC (normally closed)		
EX II 3 cll CT6		
E5 plug straight, 4 pol, without LED, M12x1		
screwed		
E5 max. 2x0.75 mm²		

Signal transmitter F4 / F5

# Accessories/ Replacement parts

SP/SMB3, SP/SMB6

Designation	Order number
Flow limiter SP/SMB3 without nozzle, without signal transmitter Gasket set for SP/SMB3	
Flow limiter SP/SMB6 without nozzle, without signal transmitter Gasket set for SP/SMB6	
Signal transmitter, Version E4 signal transmitter without coupler socket	24-1072-2115
Signal transmitter, Version E5 signal transmitter without coupler socket	24-1072-2114
Proximity switch E6 Proximity switch Sockets straight, 4-poles, M 12x1 Sockets angled, 4-poles, M 12x1 Sockets straight, 4-poles, M 12x1 with orange cable 5 m Sockets angled, 4-poles, M 12x1 with orange cable 5 m	179-990-371 179-990-372 179-990-600
Monitoring unit	84-8011-0369

### Example of a circulatingoil lubrication system

The pump (1) feeds the lubricant into the main line (2). The lubricant makes its way directly to the lube points from the flow limiters mounted in parallel (3-5).

The pump's volumetric flow has to be at least 15 % greater than the total nominal volumetric flow rates of all the connected flow limiters. Limitation of the system pressure is taken care of by the relief valve (6) built into the main line.

The sensors (or piston detectors) screwed into the flow limiters (3-5) monitor the volumetric flow. Group monitoring setups (7) evaluate the incoming signals.

#### $\otimes$ В $\overset{\sim}{\otimes}$ 12 11 10 9 õ $\tilde{\otimes}$ ÷. 8 $\otimes \otimes \otimes \otimes \otimes \otimes \otimes \otimes$ 7 6 4 $\otimes$ 1 Pump 2 Main line 3 Flow limiter 4 Flow limiter with signal transmitter 5 Flow limiter with proximity switch

6 Relief valve

7 Group monitoring unit 1-12

## Replacing plug-in nozzles

• Shut off the oil feed to the flow limiter (1)


### WARNING:

#### Burning oil hazard! Failure to shut off oil feed could result in burns.


 SP/SMB3 Loosen and remove the screw plug (2) with the help of a hexagon socket screw key (SW 8)

- SP/SMB6 Loosen and remove the screw plug (2) with the help of a hexagon socket screw key (WAF 10) press out carefully the plug-in nozzle (4)
- A brass fitting wedge (but not hard object like, for instance, a screwdriver) should be used to help press the plug-in nozzle (out of the nozzle holder with the SP/SMB 3 or out of the screw plug with the SP/SMB 6).
- SP/SMB3 Place fitting wedge between nozzle holder (3) and plug-in nozzle (4) and carefully press the old plug-in nozzle (4) with Sealing (5) out
- SP/SMB6 Place a fitting wedge between the screw plug (2) and nozzle (4), carefully press the old plug-in nozzle (4) out

- SP/SMB3 Install new plug-in nozzle (4) and Sealing (5) on the bore of the nozzle holder (3)
- A brass fitting mandrel (ø 10 mm) (but not case a hard object) should be used to help press the plug-in nozzle into the nozzle holder.
- SP/SMB3 Use a brass fitting mandrel to press the new plug-in nozzle (4) and Sealing (5) into the bore of the nozzle holder (3) without skewing
- SP/SMB6 press on new nozzle (4) onto the screw plug (2) on a plane surface. Do not tilt!
- Place the screw plug (2) in the flow limiter's threads and tighten with a hexagon socket screw key
- Open the oil feed to the flow limiter



Replacement of plug-in nozzles SP/SMB6



6 Ground plate7 Stop screw

#### Example of a circulating-oil lubrication system

### Table: Plug-in nozzles SP/SMB3

			Ta	able: Plug-in nozzles SP/SMB3
Nominalvolumetr flow <sup>1</sup> ) [l/min]	ic type nozzle	index nozzle	<b>nozzle-Ø</b> [Ø mm]	<b>Spare Part</b> complete Plug in nozzle D <sub>1</sub> Order number
6.00 6.50 6.75 7.00 7,50 8.00 8.75 9.25 9.75 10.50 11.00 11,50 12.00 12.75 13.50 14.00 14.75 15.50 16.00 16.75 17.50 18,00 18.75 19.50 20.25 21.00 21.75 22.50 23.25 24.00 25.00 26.50 28.00 30.00 34.00	$\begin{array}{c} 250\\ 260\\ 270\\ 280\\ 290\\ 300\\ 310\\ 320\\ 330\\ 340\\ 350\\ 360\\ 370\\ 380\\ 390\\ 400\\ 410\\ 420\\ 430\\ 440\\ 450\\ 440\\ 450\\ 440\\ 450\\ 440\\ 450\\ 500\\ 510\\ 520\\ 510\\ 520\\ 530\\ 540\\ 550\\ 570\\ 580\\ 600\\ 650\\ \end{array}$	$\begin{array}{c} 250\\ 260\\ 270\\ 280\\ 290\\ 300\\ 310\\ 320\\ 330\\ 340\\ 350\\ 360\\ 370\\ 380\\ 390\\ 400\\ 410\\ 420\\ 430\\ 440\\ 450\\ 440\\ 450\\ 440\\ 450\\ 440\\ 450\\ 500\\ 510\\ 520\\ 510\\ 550\\ 570\\ 580\\ 550\\ 570\\ 580\\ 600\\ 650\\ 690\\ \end{array}$	2,50 2,60 2,70 2,80 3,00 3,10 3,20 3,30 3,40 3,50 3,60 3,70 3,80 3,90 4,00 4,10 4,20 4,30 4,40 4,50 4,40 4,50 4,60 4,70 4,80 4,70 5,20 5,10 5,20 5,10 5,20 5,70 5,80 6,00 6,50	24-0455-2370 24-0455-2371 24-0455-2372 24-0455-2373 24-0455-2373 24-0455-2375 24-0455-2376 24-0455-2378 24-0455-2380 24-0455-2381 24-0455-2381 24-0455-2382 24-0455-2383 24-0455-2384 24-0455-2385 24-0455-2385 24-0455-2385 24-0455-2387 24-0455-2389 24-0455-2391 24-0455-2391 24-0455-2392 24-0455-2392 24-0455-2394 24-0455-2395 24-0455-2395 24-0455-2395 24-0455-2396 24-0455-2397 24-0455-2397 24-0455-2399 24-0455-2399 24-0455-2400 24-0455-2402 24-0455-2405 24-0455-2405

1) at a service viscosity of 300 mm<sup>2</sup>/s.


#### Note!

To order a flow limiter SP/SMB3, the customer has to create both a type designation and an order number. The latter has to be adjusted according to the flow limiter version.


The order designation on page 9 shows how to create type designation and order number.

The necessary nozzle type ( for type designation) as well as nozzle index (for order no.) can be taken from the table of plug-in nozzles SP/SMB3 on page 10.

### Key to order codes SP/SMB3



1) Please order line socket separately, see accessories on page 6



### Order example

Flow limiter design SP/SMB and size 3 (SP/SMB3) with modification letter (A), equipped with nozzle (2), with 2 point signal transmitter, version 24-230 V AC/DC (E5) and a nozzle diameter of 5.0 mm with a volume flow of 21 l/min (500) results in the following:

Type designation: **SP/SMB3A2E5/500** as well as order no.: **24-2703-8500** 

### Note

The flow limiter type SP/SMB3 is optionally available in ATEX designs:

(EX) Zone 1 (EX) Zone 21

with following characteristics:

- Body design with grounding clamp
- Type plate extended
- Operate only while using a disconnector unit
- Can be ordered with ATEX certificate

Additional ATEX versions available on demand after consultation with SKF Lubrication Systems Germany AG.

Type designation:
SP/SMB3A2 /
Order number:
24-2703

### Table: Plug-in nozzles SP/SMB6

Table: Plug-in nozzles SP/SMB6					
Nominal- volumetric flow <sup>1</sup> ) [l/min]	type nozzle	index nozzle	<b>nozzle-Ø</b> [Ø mm]	<b>Spare Part</b> complete Plug in nozzle D <sub>1</sub> Order number	
25 30 35 40 45 50 55 60 65 70 75 80 90 100 105 110 116 120 132	570 630 680 730 780 820 870 910 960 000 040 080 170 270 310 350 400 440 530	570 630 680 730 780 820 870 910 960 000 040 080 170 270 131 135 400 440 530	5.70 6.30 6.80 7.30 7.80 8.20 8.70 9.10 9.60 10.00 10.40 10.80 11.70 12.70 13.10 13.50 14.00 14.40 15.30	$\begin{array}{c} 44-0455-2357\\ 44-0455-2360\\ 44-0455-2365\\ 44-0455-2365\\ 44-0455-2367\\ 44-0455-2371\\ 44-0455-2371\\ 44-0455-2373\\ 44-0455-2374\\ 44-0455-2375\\ 44-0455-2376\\ 44-0455-2377\\ 44-0455-2378\\ 44-0455-2378\\ 44-0455-2385\\ 44-0455-2380\\ 44-0455-2381\\ 44-0455-2386\\ 44-0455-2382\end{array}$	
1) at a complete viscos	the of 200 man 2	6			

1) at a service viscosity of 300 mm $^{2}$ /s.


#### Note!

To order a flow limiter SP/SMB6, the customer has to create both a type designation and an order number. The latter has to be adjusted according to the flow limiter version.

The order designation on page 11 shows how to create type designation and order number.

The necessary nozzle type ( for type designation) as well as nozzle index (for order no.) can be taken from the table of plug-in nozzles SP/SMB6.

### Key to order codes SP/SMB6



1) Please order line socket separately, see accessories on page 6



Flow limiter design SP/SMB and size 6 (SP/SMB6) without modification letter, equipped with nozzle (2) and signal transmitter with switching voltage 24 V to 230 V AC/ DC (E5) and a nozzle diameter of 10.8 mm with a volume flow of 80 l/min (0570) results in the following:

Type designation: SP/SMB6/2E5/1080 as well as order no.: 24-2706-55080

#### Note


The flow limiter type SP/SMB6 is optionally available in ATEX designs:

> ÆX Zone 1 ÆX Zone 21

with following characteristics:

- Body design with grounding clamp
- Type plate extended
- Operate only while using a disconnector unit
- Includes avaiable ATEX certificate

Additional ATEX versions available on demand after consultation with SKF Lubrication Svstems Germany AG.



Type designation:
SP(SMB6/2/
 Order no.:
24-2706

#### Order No. 1-3001-EN

Subject to change without notice! (07/2014)

#### Important product usage information

All products from SKF may be used only for their intended purpose as described in this brochure and in any instructions. If operating instructions are supplied with the products, they must be read and followed.

Not all lubricants are suitable for use in centralized lubrication systems. SKF does offer an inspection service to test customer supplied lubricant to determine if it can be used in a centralized system. SKF lubrication systems or their components are not approved for use with gases, liquefied gases, pressurized gases in solution and fluids with a vapor pressure exceeding normal atmospheric pressure (1013 mbars) by more than 0.5 bar at their maximum permissible temperature.

Hazardous materials of any kind, especially the materials classified as hazardous by European Community Directive EC 67/548/EEC, Article 2, Par. 2, may only be used to fill SKF centralized lubrication systems and components and delivered and/or distributed with the same after consulting with and receiving written approval from SKF.

#### Brochure note

Overview brochure - Flow limiter 1-3027-FN Flow limiter SP/SMB8 0.09 to 8.18 l/min Sensor and piston detector 0.09 to 8.18 l/min Gear wheel-type flow indicator 1-3028-EN Flow limiter SP/SMB9 1-3002-EN Flow limiter SP/SMB10 0.21 to 8.15 l/min Gear wheel-type flow indicator 1-3003-EN 1-3004-EN Flow limiter SP/SMB13 6 to 38 l/min Gear wheel-type flow indicator 1-3005-EN Flow limiter SP/SMB14 25 to 132 l/min Gear wheel-type flow indicator 1-1730-EN Electrical plug-in connections

#### SKF Lubrication Systems Germany GmbH

2. Industriestrasse 4 · 68766 Hockenheim · Germany Tel. +49 (0)62 05 27-0 · Fax +49 (0)62 05 27-101 www.skf.com/lubrication This brochure was presented by:

® SKF is a registered trademark of the SKF Group.

© SKF Group 2014

The contents of this publication are the copyright of the publisher and may not be reproduced (even extracts) unless prior written permission is granted. Every care has been taken to ensure the accuracy of the information contained in this publication but no liability can be accepted for any loss or damage whether direct, indirect or consequential arising out of the use of the information contained herein.

